

Band knobs 握把旋鈕



46062
Control knob with aluminum skirt

Material: PBT
Diameter: 59 mm
Height: 25 mm



46064
Control knob with pad printing graphics

Material: PC
Diameter: 58 mm
Height: 22 mm



46074
Control knob with light texture

Diameter: 51.4 mm
Height: 29.6 mm
Shaft hole: D Type, 6.5 x 4.8 mm



46076
Plastic knob molded part only

Material: ABS or PC
Diameter: 17 mm
Height: 19.1 mm



46079
Chrome plated knob with pointer on O.D.

Material: ABS
Diameter: 57.5 mm
Height: 37 mm



46080
Chrome plated with through hole on the grip

Material: ABS
Diameter: 38.5 mm
Height: 25 mm



46117
Plastic knob with paint filled indicator line on top and side, glossy finish, fluted grip

Material: ABS
Diameter: 27.3 mm
Height: 15.5 mm
Shaft hole: D Type, 6 x 4.5 mm,



46118
Plastic knob with pad printing indicator line on top and side, glossy finish

Material: ABS
Diameter: 20.2 mm
Height: 14.5 mm
Shaft hole: D Type, 6 x 4.5 mm



46119
Plastic knob with indicator line on top and side, matte texture finish

Material: ABS
Diameter: 25.1 mm
Height: 12.6 mm
Shaft hole: ϕ 6 mm, 18 Teeth

Band knobs 握把旋鈕



46120
Plastic knob , glossy finish, indicator line on top

Material: ABS
Diameter: 12 mm
Height: 8 mm
Shaft hole: ϕ 6 mm, 18 Teeth



46121
Plastic knob with paint filled indicator line, glossy finish

Material: ABS
Diameter: 20.3 mm
Height: 13.3 mm
Shaft hole: ϕ 6 mm, 18 Teeth



46140
Plastic knob with texture finish, recess indicator line

Material: ABS
Diameter: 25.1 mm
Height: 13.3 mm
Shaft hole: D Type , 6 x 4.5 mm